



INSTRUCTIONS FOR USE



Grill
Model: XJ-7K122
Voltage: 120V~60Hz
Wattage: 500W

THIS PRODUCT IS ONLY FOR HOUSEHOLD USE ONLY. READ AND SAVE THESE SAFETY INSTRUCTIONS BEFORE USE

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

1. Read all instructions.
2. Do not touch hot surfaces.
3. To protect against electrical hazards, do not immerse power cord, plugs, or the appliance in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
6. Do not operate any appliance with a damaged power cord or plug, after the appliance malfunctions or has been damaged in any manner.
7. The use of accessories or attachments not recommended by U.S. Pro may cause hazards.
8. Do not use outdoors.
9. Do not let the power cord hang over the edge of a table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Extreme caution must be used when moving an appliance containing hot liquids.
12. To disconnect, turn the switch to 'OFF', then remove plug from the wall outlet.
13. Do not use appliance for other than its intended use.
14. Do not leave unit unattended while in use.

INTRODUCTION

The Party Grill & Raclette is an enjoyable and healthy way of cooking meats, fish and vegetables in minutes! Well-known in Europe, the art of raclette cooking encourages you and your guests to create simple yet delicious meals together. Delight in fresh foods hot off the grill while enjoying the fun and party atmosphere that this Party Grill & Raclette creates. Explore the wonderful versatility of this product as you and your guests prepare grilled foods or even appetizers such as cheese on potatoes, toast, or grilled tomatoes. Meals can as unique as the person preparing them. It's easy to use and a snap to clean.

DESCRIPTION OF PARTS



1. Grill plate
2. Handle
3. Raclette Pans
4. On/Off Switch with Indicator Light

BEFORE FIRST USE

1. Wash the Grill Plate and Raclette Pans in warm soapy water. Rinse and dry.
2. Wipe the Lower Plate and Base of the unit with a damp cloth.

NOTE: DO NOT WIPE ELEMENT.

DO NOT IMMERSE UNIT IN WATER OR ANY OTHER LIQUID.

3. Place the grill on a flat, level, heat resistant surface close to a 120 volt A.C. wall outlet.

IMPORTANT: The Grill must be at least 6" (15cm) away from walls, curtains, etc. and in a well ventilated area.

4. Season the Grill Plate and Raclette Pans (inside only) by wiping them with a paper towel moistened in 1 tbsp. (15 ml) of good quality vegetable oil.
5. Place the Grill Plate on top of the 3 Grill Plate Supports. Place the Raclette Pans on the Lower Plate.
6. Press the On/Off Switch to the On position (I) and heat for approximately 10 minutes. This will burn off any manufacturing oils still on the Grill.

NOTE: The Grill may smoke during this process. This is normal and will not last more than a few minutes.

7. Turn off the Grill by pressing the On/Off Switch to the Off position (O).

HOW TO USE

1. Place the grill on a flat, level, heat resistant surface at least 6" (15 cm) away from walls, curtains, cupboards, etc. and in a well ventilated area. Ensure that the On/Off Switch is in the Off position (O).
2. Place the Grill Plate on the 3 Grill Plate Supports.

3. Place the Raclette Pans on the Lower Plate.
4. Plug the power cord into a 120 volt A.C. wall outlet. Press the On/Off Switch to the On position (I).
5. Preheat the Grill for approximately 5 – 8 minutes.
6. Add food to the hot Grill Plate as desired. Do not use metal utensils to remove food as this may damage the Grill Plate coating. Use wooden or plastic utensils.
7. Raclette Pans can be moved on and off the Lower Plate as food is cooked and served.

NOTE: Hot Raclette Pans should be placed on a heat-resistant surface when removed from the Grill.

8. When cooking is complete, press the On/Off Switch to the Off position (0). Remove plug from wall outlet.
9. Do not move the appliance until it has completely cooled. Before moving the appliances, remove the Raclette Pans to prevent them from falling off the Lower Plate.

HELPFUL HINTS

1. Always preheat the Grill.
2. Never use metal utensils to place food on or remove food from the Grill Plate.
3. Never cut food directly on the Grill Plate or in the Raclette Pans.
4. When using the Raclette Pans on top of the Grill Plate, place gently so they do not scratch the Grill Plate.
5. Before preheating the Grill Plate, use a paper towel moistened in 1 tbsp. (15 ml) of good quality vegetable oil and spread on the cooking surface of the Grill Plate and inside Raclette Pans.

CARE AND CLEANING

1. Press the On/Off Switch to the Off position (0). Remove plug from wall outlet.
2. Allow the appliance to cool completely before cleaning.
3. Remove Grill Plate and Raclette Pans from the appliance. Wash in warm soapy water. Rinse and dry.
4. Wipe the Lower Plate/Base with a soft damp cloth.

IMPORTANT NOTES:

- **DO NOT WIPE THE ELEMENT**
- **DO NOT USE STEEL WOOL OR ABRASIVE CLEANERS ON ANY PART OF THE APPLIANCE.**
- **DO NOT IMMERSE THE LOWER PLATE/BASE OR THE PLUG IN WATER OR ANY OTHER LIQUID**