



INSTRUCTIONS FOR USE



4pcs Panini Maker

Model : XJ-9K113

Voltage: 120V~60Hz

Wattage: 1500W

HOUSEHOLD USE ONLY
PLEASE SAVE THESE INSTRUCTIONS


SAFETY PRECAUTIONS FOR YOUR PANINI MAKER

- Use well away from walls and curtains.
- Avoid using on metal surfaces e.g. sink.
- Do not use in confined spaces.
- Do not immerse the unit in water
- Ensure that the cord is kept well away from the cooking plates during use.

SAFETY PRECAUTIONS FOR ALL ELECTRICAL APPLIANCES

- Before connecting the appliance, please check if the voltage indicated on the bottom of the appliance in accordance with the main voltage in your home.
- Please locate the appliance accessible to the power socket.
- Keep the appliance away from children.
- Before first use, please check carefully if all the parts of the appliance are in good condition. If not, please contact the supplier or manufacturer.
- Never use this appliance if it is not in good condition.
- The socket used should be in accordance with the plug of the appliance.
- The surface is hot when using or before cooled. Never touch the appliance before it's cooled to avoid scald.
- This appliance is intended for domestic use only and not for commercial applications.
- The temperature of accessible surfaces may be high when the appliance is working. So **please do not touch the metal surface when it is working in order to avoid scald.**
- Keep minimum 15 cm away from the wall during operation in order to avoid the risk of fire.
- Do not let the power cord hang free.
- Keep its power cord, or that of any other appliances well away from any hot parts of the plate at all times.
- When removing the plug from the wall socket, never pull on the power cord; always grip the plug itself.
- Always remove the plug from the wall socket after use, as well as in case of any malfunction during cleaning.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- During operation, the appliance must be placed on a heat-resistant surface.
- No responsibility will be accepted if damage results from improper use, or if there instructions are not complied with.
- Do not immerse in water.

Features



Heat and Warm light

When the unit is plugged, the Heat light turns on. Once it reaches to the pre-set temperature (around 338° F) , the Heat light will turn off and the Warm light will turn on.

Securing latch

The securing latch is located on the side of the cast metal arms and is used to lock the cooking plates together when the unit is in storage.

Non-stick grill plate

The non-stick grill plates make for easy cleaning, ingredients do not stick, panini remove easily and simply wipe down after use.

Before using your Panini Maker

Before using your Panini Maker for the first time, the non-stick cooking plates must be seasoned. Plug your panini maker and pre-heat it until the warm indicator light turns on.

Wipe a small amount of butter onto the plates, rub lightly and wipe away any excess.

Note: when using your panini maker for the first time you may notice a fine smoke haze being emitted from the unit. This is normal. It is due to the initial the heating of internal components.

Using your Panini Maker

1. Plug the power into a 120V AC power outlet.
2. Pre-heat your Panini Maker until the warm light turns on.
3. Once you have prepared your snack, place the bread onto the cooking plate.
4. Gently lower the lid by pulling down the cast metal arms.
5. Allow your snack to toast for several 3 minutes, depending on the bread, filling and personal taste. Your panini maker toasts both sides of bread at the same time.
6. The cooking plates are coated with a durable non-stick coating. Some fillings such as cheese may melt and cause the panini to stick to the cooking plates. To free the panini use a plastic spatulas or wooden spoon. Never use a sharp or metal object, as this will damage the non-stick surface. **Note:** The “heat light” and “warm light” are thermostatically controlled and will cycle during cooking to ensure that the correct temperature is maintained.

7. After you have completed using your Panini Maker, remove the plug away from the socket.

Hints for best results

1. Breads with a high sugar content(fruit loaf, etc) will toast more quickly than plain sandwich bread.
2. Any type of bread can be used, white, wholemeal, kibbled wheat or wholegrain.
3. For sweet snacks, sprinkle castor sugar over the buttered sides of the bread.
4. When using raisin bread, brioche or other sweet breads which contain a high sugar content, keep in mind that they will brown much more quickly than other breads.
5. For a wholesome meal, large pieces of focaccia bread may be toasted with desired filling.
6. Bread rolls may also be toasted with desired filling.
7. For a light snack savoury or sweet bagels may be toasted with desired filling.
8. Be careful when biting into sandwiches containing fillings such as cheese, tomato or jam as they retain heat and can burn if eaten too quickly.
9. It is not necessary to butter the outside of all breads as the panini maker has non-stick cooking plates. However, to encourage even browning of bread or when using stale bread, spreading with a small amount of butter is recommended.