

THIS PRODUCT IS ONLY FOR HOUSEHOLD USE ONLY. READ AND SAVE THESE SAFETY INSTRUCTIONS BEFORE USE

Thank you for choosing this deep fryer. Please read these instructions carefully to get the best results from your appliance.

- Before connecting the appliance, please check if the voltage indicated on the bottom of the appliance is in accordance with the main voltage in your home.
- Please locate the appliance and plug accessible to the power socket.

Warning:

- Keep the appliance away from children.
- The socket used should be in accordance with the plug of the appliance.
- Make sure that the temperature controller is on the position of “off” before plugging. After plugging into the power socket, the indicator “POWER” comes on, showing the appliance is powered. When only the indicator “POWER” comes on, the appliance is not heated, when temperature controller adjust 32 °F-374 °F, “heating indication lamp” work . If the using temperature exceeds rated temperature after use, the indicator “POWER” still works and at this time, the appliance maybe very hot.
- Be sure oil tank is filled with oil to at least the marked MIN level. Do not operate appliance without oil or with an insufficient amount of oil. Do not over-fill the tank with oil past MAX mark.
- Do not open the lid when frying.
- The surface is hot when frying. Never touch the fryer before it’s cooled to avoid scald.
- Before first use, please check carefully if all the parts of the appliance are in good condition. If not, please contact the supplier or manufacturer. Never use this appliance if it is not in good condition.
- If the cable is damaged, it should be replaced by a qualified repair-man in order to avoid any hazard.
- Waste electrical products should not be disposed of with household waste.
- Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

